

WARNING		ACCESS POINT		Australia 1300 789 545 International +61 249 641068 www.safetylink.com		SafetyLink																																					
THIS SYSTEM MUST: - BE USED ONLY BY COMPETENT PERSONS. - BE USED BY PERSONS WITH RELEVANT AUTHORISATION ONLY. - HAVE ALL SAFETY PROCEDURES COMPLIED WITH AS STATED IN THE CURRENT CODES OF PRACTICE FOR WORKING AT HEIGHTS. - BE USED WITH A FULL BODY HARNESS WITH ENERGY ABSORBER COMPLYING WITH APPROPRIATE LEGISLATION, REGULATIONS AND STANDARDS. - BE CLOSED IMMEDIATELY IN THE EVENT OF A FALL, DAMAGE OR EXPOSURE TO CHEMICALS. REOPEN UPON REPAIR & RE-CERTIFICATION. - BE INSPECTED EVERY 12 MONTHS ☐ 6 MONTHS ☐				ANCHOR POINTS - QTY FALL ARREST ABSEILING LOAD RATING kN NO. OF PERSONS PER ANCHOR																																							
<table border="1"> <tr><td>month</td><td>20</td><td>year</td><td>month</td><td>20</td><td>year</td></tr> <tr><td>month</td><td>20</td><td>year</td><td>month</td><td>20</td><td>year</td></tr> <tr><td>month</td><td>20</td><td>year</td><td>month</td><td>20</td><td>year</td></tr> <tr><td>month</td><td>20</td><td>year</td><td>month</td><td>20</td><td>year</td></tr> <tr><td>month</td><td>20</td><td>year</td><td>month</td><td>20</td><td>year</td></tr> <tr><td>month</td><td>20</td><td>year</td><td>month</td><td>20</td><td>year</td></tr> </table>				month	20	year	month	20	year	month	20	year	month	20	year	month	20	year	month	20	year	month	20	year	month	20	year	month	20	year	month	20	year	month	20	year	month	20	year	LIFELINE - QTY NO. OF PERSONS PER LINE PER SPAN OTHER LOAD RATING kN NO. OF PERSONS PER ANCHOR			
month	20	year	month	20	year																																						
month	20	year	month	20	year																																						
month	20	year	month	20	year																																						
month	20	year	month	20	year																																						
month	20	year	month	20	year																																						
month	20	year	month	20	year																																						
INSTALLER/CERTIFIER: SYSTEM IDENTIFICATION NO: INSTALLED/CERTIFIED DATE: DUE SERVICE DATE:																																											

- ▲ Size 300mm x 120mm x 1mm.
- ▲ Essential entry point information for safety system.
- ▲ Notes installer information, safe use and inspection details.
- ▲ Made from the same material as road signs for durability.

Easy to read, system information showing for example:

Anchor Points =	Number of anchor points on system.
Fall Arrest =	indicate which anchors are fall arrest only.
Abseiling =	indicate which anchors are abseiling and fall arrest.
Load Rating =	Load rating of anchor points on system.
No. of Persons/Anchor =	Number of persons allowed on system and number of persons allowed on each anchor at any one time.
Lifeline =	Number of staticline systems.
No, of persons/line =	Number of persons allowed on staticline system at any one time.
Span =	Number of persons allowed per span at any one time.
Other =	Number of additional items in system.
Load rating =	Load rating of additional items.
No. of persons =	Number of persons allowed on additional items at any one time.
Installer/Certifier =	write the name of installer or certifier.
Identification No =	write the reference number for the job, for your reference.
Installed/Certified Date =	write the date system installed or certified.
Due Service Date =	write the date system is due for service.



www.safetylink.com



Catalogue



Safety Centre
Training

Product Code: WARNG001

POSITIONING OF SAFETYLINK ANCHOR POINT

The first must be in a position easily and safely reached by a secured ladder or a manhole access point.



© 2018, SafetyLink Pty Ltd, Australia.

Patents: SafetyLink Pty Ltd has a multitude of patents, patents pending, design applications, trademarks and copyrighted documents both lodged and issued. Should you wish to know the progress of our intellectual property on a specific product please email us on ip@safetylink.com and quote the product code.

Doc ID: MKT-159 Version: 11.0