







INSTALLATION HANDBOOK

TUFF-POST LIFELINE

SafetyLink is an innovative anchor company achieving success and keeping you safe whilst working at heights.

-  ROOF ANCHORS
-  HORIZONTAL LIFELINES
-  PERMANENT LADDERS
-  LADDER STABILISERS
-  TEMPORARY ANCHOR



Read entire handbook before installing SafetyLink products. All products must be installed in accordance with SafetyLink's installation handbook, using only products supplied by SafetyLink Pty Ltd. Failure to follow all warnings and instructions may result in serious injury or death.



SafetyLink Pty Ltd
AU: 1300 789 545
INT: +61 2 4964 1068
FAX: +61 2 4964 1069
info@safetylink.com

www.safetylink.com

TABLE OF CONTENTS

INSTALLATION OF SAFETYLINK TUFF-POST

WARNINGS	3
MAINTENANCE – PERIODIC INSPECTIONS	4
WARRANTIES	5
TUFF-POST – CONCRETE MOUNTED COMPONENTS	6
TUFF-POST – CONCRETE INSTALLATION	7
POSITIONING OF TUFF-POST	7
LOCATING THE STEEL REINFORCING IN THE CONCRETE.....	7
DRILLING THE 4 X 14MM HOLES.....	7
PREPARING THE 4 X 14MM HOLES	7
TUFF-POST – CONCRETE INSTALLATION	8
INSTALL 4 X ANCHOR ROD	8
TUFF-POST – STEEL MOUNTED COMPONENTS	9
TUFF-POST – STEEL INSTALLATION	10
POSITIONING OF TUFF-POST	10
DRILLING THE 4 X 12MM HOLES.....	10
PREPARING THE 4 X 12MM HOLES	10
INSTALL 4 X M12 BOLTS MINIMUM A4-70 GRADE	10
FITTING THE HEIGHT SAFETY SYSTEM TO THE TUFF-POST	10
EXAMPLE: HORIZONTAL LIFELINE ON PITCHES BELOW 25 DEGREES	11
IN CASE OF ACCIDENT	12



Safety Centre Training



Catalogue



www.safetylink.com
Terms/Conditions/Warranties

READ CAREFULLY SOMEONE'S LIFE DEPENDS ON IT

- The building or structure for the anchorages should be assessed by an engineer, unless it is clear to a competent height safety installer that the structure is adequate.
- SafetyLink Height Safety Systems must only be installed as per our installation guides, to structures as specified in the installation manual for each product.
- All safety procedures must be complied with in accordance with the current safety code(s) of practice(s) for working at heights. Ensure safety at all times by being attached to suitable anchor points and approved safety equipment or approved scaffolding.
- Installation is to be carried out by, or under the supervision of a competent height safety installer.
- To prevent galling of non-permanent or adjustable stainless steel components use nickel anti-seize or similar boundary layer lubricant.
- Recommended waterproofing for roof tiles: *Sika Flex Co-Polymer Sealant*.
- Recommended waterproofing for metal roof: *Silicone Sealant Neutral Cure*.
- Recommended chemical anchor: Hilti RE500 or Hilti HY200 as per Hilti Product Supplement Data sheets.
- All bolt threads must be applied with Loctite 243 thread-locker prior to assembly. (IMPORTANT NOTE: Before applying Loctite 243 use Loctite 7471 primer to activate the surface according to manufacturer's instructions).
- A personal energy absorber or a fall-arrest device with a personal energy absorber must be used in conjunction with all SafetyLink Anchorages and Lifeline systems.
- SafetyLink Horizontal Lifelines are not intended to be installed on roof pitches greater than 25 degrees.

 **MAXIMUM NUMBER OF USERS PER SYSTEM IS FOUR (4).**

 **MAXIMUM NUMBER OF USERS PER SPAN IS TWO (2).**

 **REFER TO SYSTEM INFORMATION FOR SITE SPECIFIC USE.**



MAINTENANCE – PERIODIC INSPECTIONS

All items of height safety equipment which are in regular use shall be subjected to periodic inspection and servicing. These regular scheduled inspections and servicing must be carried out by a competent height safety installer (*refer to AS/NZS 1891.4:2009 if clarification required or contact SafetyLink*).

SafetyLink Anchorages (*In accordance with AS/NZS 1891.4:2009*)

ALL ANCHORAGES MUST BE INSPECTED EVERY 12 MONTHS.

Procedures to be followed at inspection time:

- Visually inspect anchors for signs of deterioration.
- The FrogLine End, Intermediate and Corner anchor points have energy absorbing regions and stabilising joints. If these energy absorbing regions are expanded this will indicate the anchor point has arrested a fall and should be replaced. Similarly, if the stabilising joints have been broken this would also indicate the anchor point has arrested a fall and should be replaced. (*The design features of the FrogLine's curved profile provides the initial shock absorbing capabilities in the event of a fall. Further extension is provided in the serpentine shapes which progressively dissipate and absorb energy whilst retaining their strength. This lessens the force on the person falling and the structure the anchor is attached to.*)
- Visually inspect the components of the anchor for corrosion, superficial surface marking is permitted while deeper corrosion or pitting would require attention.
- Manually (by hand) check the 16mm bolt securing the FrogLine Base to the Concrete Insert for rigidity and tightness. If the Bolt can turn in the anticlockwise direction it will require attention.
- Visually inspect the attachment component of the anchorage where practically possible.
- Visually inspect the parent structure for modifications or deterioration which might lead to loss of anchorage strength.
- Check the full length of the stainless steel cable for any evidence of wear, cuts, looseness, extension, inter-strand wear, corrosion, stiffness, brittleness or fraying.
- Check the integrity of cable terminations and that lifeline tensioners are correctly adjusted (80kg/0.8kN/800N) and lock nuts are tensioned correctly.
- Check for the presence of contaminants or exposure to corrosive or extreme environment signs may include discoloration, crystallising or oxidation. These could significantly reduce the safe working load of the Lifeline.
- Run the FrogLine Shuttle along the full length of the life line to verify its correct function.
- For Concrete Installation Only: To comply with Australian Standards, each ConcreteLink must be tested after installation and at every recertification inspection. Ensure you wait the recommended curing time as specified by the chemical anchor instructions. The pull test can be done using a 16mm threaded eyebolt. Test consists of ultimate pull out force proof loading to 50% of design purpose of anchorage.

IN ADDITION TO SAFETYLINK PTY LTD EQUIPMENT, ALL ANCILLARY EQUIPMENT MUST BE INSPECTED IN ACCORDANCE WITH APPLICABLE REGULATORY REQUIREMENTS AND THE MANUFACTURER'S INSTRUCTIONS.



**FOR MAINTENANCE ADVICE AND SERVICES PLEASE CONTACT SAFETYLINK
ON +61 249 641068 OR 1300 789545 FOR YOUR NEAREST SAFETYLINK INSPECTION SERVICE CENTRE
OR EMAIL: info@safetylink.com**

WARRANTIES

EXTRACT: SafetyLink Pty Ltd STANDARD TERMS AND CONDITIONS

- 11.1 To the extent permitted by law all implied conditions, warranties and undertakings are expressly excluded.
- 11.2 Except as provided in this clause the Company shall not be liable for any loss or damage, whether direct or indirect (including consequential losses or damage) arising out of any breach of contract by the Company or any negligence of the Company, its employees or agents.
- 11.3 Should the Company be liable for a breach of a guarantee, condition or warranty implied by the Australian Consumer Law (not being a guarantee, condition or warranty implied by sections 51, 52 and 53 of that Law) then its liability for a breach of any such condition or warranty express or implied shall be limited, at its option, to any one or more of the following.
- A) in case of Goods
- (I) the replacement of the Goods or the supply of equivalent Goods.
 - (II) the repair of the goods,
 - (III) the payment of the cost of replacing the Goods or acquiring equivalent Goods.
 - (IV) The payment of the cost of having the Goods repaired.
- Provided that any such Goods are returned to the Company by the Purchaser at the Purchaser's expense.
- B) in the case of services
- (i) the supply of the services again,
 - (ii) the payment of the cost of having the services supplies again.
- 11.4 The Company will not liable for the costs of recovery of the Goods from the field, loss of use of the Goods, loss of time, inconvenience, incidental or consequential loss or damage, nor for any other loss or damage other than as stated above, whether ordinary or exemplary, caused either directly or indirectly by use of the Goods.
- 11.5 The Company warrants that at the time of shipment, Products manufactured by it will be free from defects in material and workmanship. In the absence of a modified written warranty, the Company agrees to making good any such defects by repairing the same or at the Company's option by replacement, for a period of (1) one year from the date of shipment. This limited warranty applies provided that:
- (a) defects have arising solely from faulty materials or workmanship;
 - (b) the Products have not received maltreatment, inattention or interference;
 - (c) **the Products have been installed in accordance with the Company's Installation Handbooks using only products supplied by the Company;**
 - (d) accessories used with the Products are manufactured by or approved by the Company;
 - (e) the Products are maintained in accordance with Australian Standard 1891.4 (section 9).
 - (f) you notify any claim under this warranty to SafetyLink in writing to the address below no later than 14 days after the event or occurrence concerning the produce giving rise to the claim and you pay all costs related to your claim.

This warranty does not apply to any defects or other malfunctions caused to the Goods by accident, neglect, vandalism, misuse, alteration, modification or unusual physical, environment or electrical stress.

Please note that the benefits to the purchaser (as a consumer) given by this warranty are in addition to your other rights and remedies under the Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

- 11.6 If any goods are not manufactured by the Company, the guarantee of the manufacturer thereof shall be accepted by the Purchaser as the only express warranty given in respect of the goods.
- 11.7 Except as provided in this clause 11, all express and implied warranties, guarantees and conditions under statute or general law as the merchantability, description, quality, suitability or fitness of the Products for any purpose or as to design, assembly, installation, materials or workmanship or otherwise are hereby expressly excluded (to the extent to which they may be excluded by law).

PLEASE SEE SAFETYLINK PTY LTD FULL STANDARD TERMS OF CONDITIONS OF SALE FOR FURTHER REFERENCE.



TUFF-POST – Concrete Mounted Components

CONCRETE MOUNTED LIFELINE

COMPLETE UNIT	ORDER CODE 300mm TUFF-POST	ORDER CODE 600mm TUFF-POST
END	STAT.FROGTUFF002C - 300	STAT.FROGTUFF002C - 600
CORNER	STAT.FROGTUFF003C - 300	STAT.FROGTUFF003C - 600
INTERMEDIATE	STAT.FROGTUFF001C - 300	STAT.FROGTUFF001C - 600
INTERMEDIATE EXTENDED	STAT.FROGTUFF008C - 300	STAT.FROGTUFF008C - 600


PRODUCT COMPONENTS	DESCRIPTION	MATERIALS	QTY
FROGLINE INT	FrogLine Base Intermediate	316 SS	1
FROGLINE INT_EXT	FrogLine Base Intermediate Extended	316 SS	1
FROGLINE END	FrogLine Base End	316 SS	1
FROGLINE CNR	FrogLine Base Corner	316 SS	1
FROGLINE BOLT	FrogLine Eyebolt M16 x 35mm	316 SS	1
WASHER M20	Washer: M20	316 SS	1
O-RING	O-RING	Black Plastic	1

300mm BASE COMPONENTS	DESCRIPTION	MATERIALS	QTY
TUFF-POST300	TUFF-POST 300mm	316 SS	1
CON-M12x160	Anchor Rod M12X160, M12 Nut, M12 Spring Washer & M12 Washer	316 SS	4

600mm BASE COMPONENTS	DESCRIPTION	MATERIALS	QTY
TUFF-POST600	TUFF-POST 600mm	316 SS	1
CON-M16x160	Anchor Rod M16X160, M16 Nut, M16 Spring Washer & M16 Washer	316 SS	4

** Recommended chemical anchor: Hilti HIT-HY200r or equivalent.

*Innovative
Fall Protection*



TUFF-POST – Concrete Installation

All safety procedures must comply in accordance with the current safety code(s) of practice(s) for working at heights. Ensure safety at all times during and after installation by using an appropriate height safety system.

TUFF-POST is designed to raise the ground height of a height safety system therefore TUFF-POST **must only** be used in conjunction with a SafetyLink lifeline or energy absorbing eyebolt system.

POSITIONING OF TUFF-POST

- The pendulum effect applies.
- TUFF-POST must be in a position easily and safely reached from a safe access point.
- TUFF-POST must **not** be installed close to concrete edges, minimum distance to any concrete edge is **150mm**.
- **Minimum concrete thickness 150mm.**
- **Minimum concrete grade MPA32.**
- **Minimum anchor rod embedment 115mm.**
- **Recommended chemical anchor: Hilti HIT-HY200r or equivalent.**

- ⚠ If any doubt exists with the strength of the structure an engineer should make the assessment.
- ⚠ Installation must be carried out by, or under the supervision of a competent height safety installer.
- ⚠ During installation you must be safe at all times.

LOCATING THE STEEL REINFORCING IN THE CONCRETE

Use of a digital metal detector (example: Bosch DMO 10) to locate the steel reinforcing in the concrete is recommended when determining the anchor hole locations for the TUFF-POST. This ensures steel is avoided when drilling.

DRILLING THE 4 x 14mm HOLES

Drill a 14mm hole to a minimum depth of 115mm with a hammer drill and masonry drill bit, *refer to Drawing 2*.


PREPARING THE 4 x 14mm HOLES

The holes must be moisture and dust free. Remove dust using compressed air, small brush and vacuum cleaner.

Drawing 1



Drawing 2



SafetyLink®
Innovative
Fall Protection

TUFF-POST – Concrete Installation

INSTALL 4 x ANCHOR ROD

The TUFF-POST 300mm must be held down with 4x anchor rods.

300mm Post use CON-M12x160

600mm Post use CON-M16x160


Anchor rod length must be a minimum of 160mm however will be determined based on water proofing membrane thickness under the TUFF-POST.

- Fill 14mm holes with chemical adhesive gel as specified with the Hilti product use data sheet.
- Fit anchor rods ensuring a minimum of 115mm for 300mm and 600mm posts is embedded in the concrete and chemical adhesive gel.
- Remove any chemical adhesive gel that has been displaced from the anchor hole during installation.
- Allow chemical adhesive gel to cure to full strength as indicated in the Hilti product use manual.
- Once chemical adhesive gel has cured each Anchor Rod will need to be load tested with a calibrated pull testing machine to **7.5kN**, refer to Drawing 3.

Annual recertification will require the TUFF-POST to be load tested as a complete unit with a calibrated pull testing machine to **7.5kN**, refer to Drawing 4.

This is completed by connecting the pull test machine to the top of the TUFF-POST at the 16mm thread. If TUFF-POST is installed with a Lifeline system a load test eyebolt will be present for this test to be completed. If TUFF-POST is installed with an energy absorbing eyebolt, a test eyebolt will need to be installed and the energy absorbing eyebolt reinstalled once the test is completed. **NEVER COMPLETE LOAD TESTS ON ENERGY ABSORBING EYEBOLTS, LIFELINE END AND INTERMEDIATES.**

Drawing 3



Drawing 4

Tuff-Post End - 7.5kN Pull



TUFF-POST – Steel Mounted Components


STEEL MOUNTED LIFELINE

COMPLETE UNIT	ORDER CODE 300mm TUFF-POST	ORDER CODE 600mm TUFF-POST
END	STAT.FROGTUFF002S - 300	STAT.FROGTUFF002S - 600
CORNER	STAT.FROGTUFF003S - 300	STAT.FROGTUFF003S - 600
INTERMEDIATE	STAT.FROGTUFF001S - 300	STAT.FROGTUFF001S - 600
INTERMEDIATE EXTENDED	STAT.FROGTUFF008S - 300	STAT.FROGTUFF008S - 600

PRODUCT COMPONENTS	DESCRIPTION	MATERIALS	QTY
FROGLINE INT	FrogLine Base Intermediate	316 SS	1
FROGLINE INT_EXT	FrogLine Base Intermediate Extended	316 SS	1
FROGLINE END	FrogLine Base End	316 SS	1
FROGLINE CNR	FrogLine Base Corner	316 SS	1
BOLT-M16x35mm-SS	Bolt: 16mm x 35mm Set Screw	316 SS	1
WASHER M20	Washer: M20	316 SS	1
O-RING	O-RING	Black Plastic	1

300mm BASE COMPONENTS	DESCRIPTION	MATERIALS	QTY
TUFF-POST300	TUFF-POST 300mm	316 SS	1
BOLT-M12x50mm-SS	Bolt: M12x50mm Set Screw	316 SS	4
WASHER M12	Washer: M12	316 SS	4
NUT NYLOC M12_316	Nut: M12	316 SS	4

600mm BASE COMPONENTS	DESCRIPTION	MATERIALS	QTY
TUFF-POST600	TUFF-POST 600mm	316 SS	1
BOLT-M16x50mm-SS	Bolt: M16x50mm 316SS Set Screw	316 SS	4
WASHER M16	Washer: M16 316 Stainless Steel	316 SS	4
NUT NYLOC M16_316	Nut: M16 316 Stainless Steel	316 SS	4



TUFF-POST – Steel Installation

All safety procedures must comply in accordance with the current safety code(s) of practice(s) for working at heights. Ensure safety at all times during and after installation by using an appropriate height safety system.

TUFF-POST is designed to raise the ground height of a height safety system therefore TUFF-POST **must only** be used in conjunction with a SafetyLink lifeline or energy absorbing eyebolt system.

POSITIONING OF TUFF-POST

- The pendulum effect applies.
 - TUFF-POST must be in a position easily and safely reached from a safe access point.
 - TUFF-POST must **not** be installed close to steel edges, minimum distance to any steel edge is **50mm**.
 - **Minimum steel thickness 12mm.**
- ⚠ If any doubt exists with the strength of the structure an engineer should make the assessment.
- ⚠ Installation must be carried out by, or under the supervision of a competent height safety installer.
- ⚠ During installation you must be safe at all times.

DRILLING THE 4 x 12mm HOLES

Drill 4 x 12mm holes in suitable locations with a power drill and 12mm drill bit.

PREPARING THE 4 x 12mm HOLES

The holes must be clear and free from burrs.

INSTALL 4 x M12 bolts minimum A4-70 grade

- The TUFF-POST must be held down with a minimum of 4 x M12 bolts.
- Bolts must be a minimum of M12 and A4-70 Grade, length will be a minimum of 35mm and ultimately determined by the thickness of steel the post is anchored to.
- A nyloc nut or thread locker must be applied to all bolts to prevent the bolts from coming loose.


No load testing is required when installing to steel structures, however inspection of the structure must be made and identified as capable of supporting the height safety system in the event of a fall.

FITTING THE HEIGHT SAFETY SYSTEM TO THE TUFF-POST

- Once the TUFF-POST is correctly installed to the structure, the Lifeline System or Energy Absorbing Eyebolt system can be installed. Refer to FrogLine Manual.
- The system components are only to be installed to the TUFF-POST with a minimum grade A4-70 Stainless Steel M16 bolt.
- Thread locker must be applied to all threads before installing to the TUFF-POST. **Use Loctite on the thread to ensure that the unit cannot be tampered with (IMPORTANT NOTE: Before applying Loctite 243 use Loctite 7471 primer to activate the surface according to manufacturer's instructions).**

EXAMPLE: HORIZONTAL LIFELINE ON PITCHES BELOW 25 DEGREES

All working at heights safety procedures must be complied with when installing SafetyLink Height Safety Systems. For more information refer to your state or territories current legislation, regulations, policies and codes of practices. Horizontal height safety lifelines must only be installed and used by competent people with relevant current height safety qualifications.



This is a guide only

SAFETYLINK HEIGHT SAFETY SYSTEMS MUST ONLY BE INSTALLED AS PER OUR INSTALLATION GUIDES, TO STRUCTURES AS SPECIFIED IN THE INSTALLATION MANUAL FOR EACH PRODUCT. SHOULD ANY DOUBT EXIST IN REGARD TO THE STRUCTURES INTEGRITY AN ENGINEER SHOULD BE CONSULTED.



IN CASE OF ACCIDENT

⚠ A FALL RESCUE PLAN SHOULD BE DEVELOPED PRIOR TO USING SAFETYLINK EQUIPMENT.

⚠ PERSONS WORKING AT HEIGHTS SHOULD NOT WORK ALONE.

It is critical that before using any SafetyLink Systems a fall rescue plan is in place for any persons suspended mid-air following a fall. Serious injury or death can occur in a matter of minutes, particularly if a person's movement or breathing is restricted or loss of consciousness has occurred. In accordance with your fall rescue plan and appropriate first aid procedures it is essential to remove the person from the suspended position as quickly as possible.

IN ACCORDANCE WITH AS/NZS 1891.4:2009 CLAUSE 9.5

EQUIPMENT WHICH HAS ARRESTED A FALL OR SHOWS A DEFECT

Any piece of equipment including both personal and permanently installed items, which has been used to arrest a fall or which shows any defect during operator or periodic inspection shall be withdrawn from service immediately and a replacement obtained if necessary. A label indicating the condition or defect should be attached to the equipment, and it should be examined by a competent height safety installer who will decide whether the equipment is to be destroyed or repaired if necessary and returned to service. In the latter case, details of any repair shall be documented, and a copy given to the operator.



SafetyLink®

*Innovative
Fall Protection*



FS 707792

DISTRIBUTOR:



SafetyLink Pty Ltd | ABN 83 081 777 371

⚠ Phone: 1300 789 545 or +61 2 4964 1068 | Fax: 1300 738 071 or +61 2 49641069

info@safetylink.com | www.safetylink.com