

SWAGELESS

Lifeline Tensioners and Terminations



SCAN ME
FrogLine
In Use




SCAN ME
Terms and
Conditions



SCAN ME
Catalogue

DATA SHEET



Swageless Tensioner

Product Code: STAT.TENSR002

- Affords simple installation.
- Suits 8mm, 7x7 & 7x19 cable.
- Stainless steel construction.
- For use on Horizontal and Vertical Lifelines.

Swageless Tensioner with Tension Indicator

Product Code: STAT.TENSR004

- Tension fork indicator.
- Compact design for easy installation.
- Pre-Tension indicator disk frees at 800n.
- Suits 8mm, 7x7 & 7x19 cable.
- Stainless steel construction.
- For use on Horizontal Lifelines.

Swageless Fork Termination

Product Code: STAT.TERMN002

- Fork terminal.
- Affords simple installation.
- Suits 8mm, 7x7 & 7x19 cable.
- Stainless steel construction.
- For use on Horizontal and Vertical Lifelines.



© 2018, SafetyLink Pty Ltd, Australia.

Patents: SafetyLink Pty Ltd has a multitude of patents, patents pending, design applications, trademarks and copyrighted documents both lodged and issued. Should you wish to know the progress of our intellectual property on a specific product please email us on ip@safetylink.com and quote the product code.

Doc ID: MKT-153 Version: 10.0

SWAGELESS

Lifeline Tensioners and Terminations



SCAN ME
FrogLine
In Use



SCAN ME
Terms and
Conditions



SCAN ME
Catalogue

DATA SHEET



FS 707792



Jaw housing
Hauptstück




Jaws
Backen



Brass Ring
Messing Ring



Head
Kopfteil



Make sure that the cable matches the terminal.

The SS terminal use only for 8mm 7x7 and 7 x 19 Stainless Wire.

Do no reuse jaws or house.

- 1 Slide the jaw housing in place on the cable.
- 2 Slide the jaws onto the cable, ensuring there is equal space between the jaws.
- 3 Place the brass pressure ring on the end of the cable. Make sure that the distance from the pressure ring to the end of the cable is 5-8mm.
- 4 Slide the jaw housing over the jaws.
- 5 The terminal can now be assembled. Screw the head on the jaw housing with a torque wrench – **min. 58 Nm (43Lbf ft)**, Tighten the lock nut with **min. 50 Nm (36 Lbf ft)**.

Note: after the first dynamic load the terminal **MUST** be tightened again. When assembling Swageless Terminals the breaking strength of the cable will be reduced by 0-15%.

The user is responsible for choosing the proper cable, and for correct assembly.



© 2018, SafetyLink Pty Ltd, Australia.

Patents: SafetyLink Pty Ltd has a multitude of patents, patents pending, design applications, trademarks and copyrighted documents both lodged and issued. Should you wish to know the progress of our intellectual property on a specific product please email us on ip@safetylink.com and quote the product code.

Doc ID: MKT-153 Version: 10.0